

Rössle Speedcontrol



Mit der RÖSSLE 3-Speed SpeedControl lassen sich die Bürsten BISAM 44 und BIBER 22 präzise steuern. Die SpeedControl bietet in beiden Laufrichtungen – links und rechts – drei verschiedene Drehgeschwindigkeiten. Über die Pfeiltasten können die Geschwindigkeiten durch mehrfaches Drücken erhöht oder verringert werden. Ein zwei Sekunden langes Drücken der Ein-/Ausschaltaste aktiviert direkt die höchste Drehgeschwindigkeit. LEDs zwischen den Tasten zeigen an, welche der drei Geschwindigkeitsstufen aktuell aktiv ist.




rössle

Technik für saubere Teiche

Rössle Speedcontrol



The RÖSSLE 3-Speed SpeedControl allows precise control of the BISAM 44 and BIBER 22 brushes. The SpeedControl offers three different rotation speeds in both directions – left and right. Using the arrow buttons, the speed can be increased or decreased by pressing multiple times. Pressing the on/off button for two seconds instantly activates the highest rotation speed. LEDs between the buttons indicate which of the three speed settings is currently active.



rössle

Technology for clean ponds